



*15% max for flow control/runoff treatment in rural areas.

Section A-A

Notes:

1. This trench shall be constructed so as to prevent point discharge and/or erosion.
2. Trenches may be placed no closer than 50 feet to one another. (100 feet along flowline)
3. Trench and grade board must be level. Align to follow contours of site.
4. Support post spacing as required by soil conditions to ensure grade board remains level.

NOT TO SCALE



Figure II-4.2. Alternative Flow Dispersion Trench

July 2021