



Curb Port

NOT TO SCALE



**Figure II-4.19. Flow Spreader Option D:
Through-Curb Port**